

Winterizing for the Vac – Alert system

- 1) Remove the Vac-Alert at the union, bottom side. Take care not to misplace the o-ring that is on the underside of the unit.
- 2) Install # 8 standard rubber winter plug, in the opening where the Vac- Alert was located.
- 3) Blow out the lines with air per normal procedure.
- 4) Air lock the pool/spa drain lines by closing the main drain shut-off valve (s).
- 5) After the Vac-Alert is removed, be sure to drain any water remaining in the unit prior to storage. Draining the unit involves removing the vent screen, and then depressing the piston. Once the piston is depressed, water in the unit will drain out. After draining, the piston should be reset and the vent screen re-installed prior to storage.
- 6) Store the Vac- Alert in the original box, or in a way that the Vac-Alert is protected and the o-ring is not lost.
- 7) Be sure to advise the end user that the Vac-Alert must be installed and tested prior to re-opening the pool.